



**BORMA WACHS®**

Wood Professional Cosmetics

## Technical data sheet

# Finishing Technology for interiors FI22 Classical Shabby

## Finishing for Furniture

1. On a clean and dry surface apply a uniform coat of Shabby Kreide Farbe, by brush, a colour of your choice. If you're making the decoration on already treated furniture, we recommend a preliminary sanding (grit 240-320).
2. Wait till complete drying (4-6h).
3. Using a Softwax stick (cod. 1000) apply some small quantities of wax, possibly softened by the warmth of your hands, somewhere on the surface. The thickness applied must be at least 1-2mm to get an evident scraped effect. The colour of the stick should be the nearest possible to that of the Shabby paint chosen for the next layer.
4. Apply an abundant layer of Shabby paint, a colour of your choice, contrasting the first one. The application should be generous; brushstrokes, surplus in the corners and drippings will enhance the vintage look and the final patinas' effect.
5. Let dry for 4-6 hours.
6. Using the Touch up Spatula (code 6447) and an abrasive pad, remove the soft wax that was covered by the last layer of Shabby paint. Remove the residuals of soft wax with some transparent Hardwax Oil 7030 (code 2960). This procedure lead to a natural scraped effect.
7. Complete the effect with Antique Patina (code3560), applied by brush and almost immediately removed by rag.
8. Protect the effect with Hardwax Oil 7030 (code 2960) or Antikwachs (code 3420) transparent or coloured.

