



**BORMA WACHS®**

Wood Professional Cosmetics

## Technical data sheet

# Aged Effect 2016

## Natural Antique Effect for Interiors on Larch

1. Apply HOLZ ANTIX 2008 by brush or by spray.  
Covering: 40-50 g/m<sup>2</sup>  
Drying time: 6-8 h (20°C)
2. Lightly sand the wooden surface with scotch brite or abrasive paper grit 220.
3. Apply a coat of transparent Hard Wax Parquet Oil 1030 by brush, spray or roll. Remove any excess of oil with a soft and clean cloth, within two minutes from the application.
4. Let the oil coat dry for at least 4 hours (20°C).
5. Lightly sand the wooden surface with scotch brite or abrasive paper grit 220.
6. Apply a second coat of transparent Hard Wax Parquet Oil 1030 by brush, spray or roll. Remove any excess of oil with a soft and clean cloth, within two minutes from the application.  
Covering: 60 g/m<sup>2</sup>
7. Complete drying after 24 hours (20°C) from the application of the second coat.

